



Scan To Install



DangleElite APP

**WARNINGS:**

- \* Do not expose its components to extreme heat or cold.
- \* Keep the product away from rain, water, or other wet conditions.
- \* Any modifications to the product or games will void the warranty.

**DANGER:**

- \* To avoid electric shock, do not immerse the product in water. Clean only with a dry or slightly damp cloth.
- \* Unplug the panel after charging; do not leave it plugged in for prolonged periods.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

# DIGITAL STICKHANDLING TRAINER (APP) INSTRUCTION

HITS TIME  
00 45



Scan To Install



DangleElite APP



FB  
potenthockey



INS  
potenthockey



Tik Tok  
potenthockey

WEBSITE  
[www.potenthockey.com](http://www.potenthockey.com)



Simple Is  
often **B**etter

Designed in Canada

**PACKING LIST**

- Smart Stickhandling Trainer × 1
- Sensor Ball × 1
- USB cable × 1
- Sensor Puck × 1

**SPECIFICATIONS**

- Size: 38cm (Length) × 7cm (Height) × 5 (Arms)
- Powerinput: AC100-240 - 50/60 HZ 0.2A Max
- Output: 5V

**INSTRUCTION**

**How to Use the Dangler**

Five targets are randomly lit and scored.

**TIME & HITS**

TIME: 45s

HITS: when the sensor ball/puck passes under the LED light ,you will get a score.

**CONTROLLER INSTRUCTION**

ON/OFF——Power

CHARGING LED

Charging display red, full display green

**SPEED——Speed switch**

P1:the light changes every 2 seconds

P2:the light changes every 5 seconds

**Without the APP**

- You have access to P1 and P2 modes
- Simply select the desired mode from controller to start training.

**With the APP**

- Download the DangleElite APP
- Set up the App (link App and Product)




**DangleElite APP Scan To Install**

**Unlock your full potential by subscribing to the DangleElite membership! Hockey**

Gain access to exclusive puck rewards program, experience video recording and replay, receive real-time training feedback, compete in Air Battles, and track your progress with rich performance stats and the global leaderboard.

Don't miss the opportunity to elevate your skills—visit our website [potenthockey.com](http://potenthockey.com) or the APP to subscribe today!



Step 1: Select card Digital Stickhandling Trainer to enter training mode.

Step 2: Click the Connect button in the upper right corner.

Step 3: Select Stickhandling.

Step 4: Power and Bluetooth icon power, connection complete.

**Shutdown**

Turning off the controller powers off .

- Manual: Press the power button on the controller.
- Automatic: The system shuts down after 5 minutes of standby.

**ATTENTION**

This product does not need to replace the battery, if the lights becomes dark or cannot be started, please use the power adapter to charge in time.

Sensor ball/puck is only for use on Smart Stickhandling Trainer.

Sensor ball/puck is not for shooting.

Operating temperature: -20°C~40°C

Battery working hours: 7 hrs

**STRUCTURE CHART**

